# Foldable Dispenser Carts SDC 03 and SDC 03 Plus

Fire brigade

Liquidation

of Accidents

Transport

Industry

& Logistics

Dispenser

Carts

Usage

The Sorbent Dispenser Cart has been designed for use wherever it is necessary to use powdered sorbents to treat accidental leakages of harmful fluids (e.g., oil products, chemical fluids). For all currently used sorbents (including light and fibrous materials).

Ð

Easily portable,

of sorbents

ensures even distribution

Quick and easy to deploy in seconds

ECCOTARP HazMat

- Two types SDC 03 (manually operated) and SDC 03 Plus (magnetic elements)
- Packed cart takes minimal space
- Simple adjustment for the thickness and breadth of application (max. 17 in)
- Adjustable handle
- Reinforcement of parts subject to stress

Quick and easy to deploy (assembles and dismantles in seconds)





Height-adjustable position of the handle with protection against full extension.

Folded cart fits comfortably into a fire truck. Adjustable anchor ensures stability of the cart while filling with sorbent. Space-saving storage.

Manually operated adjustable anchor SDC 03 cart – requires manual loosening and tightening of plastic nuts to extend the support.

Adjustable magnetic anchor for cart SDC 03 Plus – simple and fast use with the toe of the shoe.

Manually operated profiled spreader plate SDC 03 – for correct setting it is necessary to manually loosen and tighten the cover nuts. A special gear allows application by moving

A special gear allows application by moving the truck forward. Moving back automatically stops spreading (sorbent saving).





SDC 03 Plus has a magnetic sorbent spreader plate. The cover is operated with the toe of the shoe and when moving upwards, it stops on special stops adjustable according to the sorbent spreading density requirement.

SDC 03 Plu

Maximum performance: thanks to the special construction, the sorbent is applied by a combination of a paddle feeder and wheel vibrations. The sorbent is evenly distributed to the contaminated area. Examples of use



## **SDC 03**

Dispenser cart with manually operated adjustable anchor and manually operated profiled spreader plate. Both elements must be manually adjusted by loosening and tightening the plastic nuts.

## Top quality

Stressed areas are strengthened. Strength materials, stainless steels, solid polyurethane, industrial bearings are used in the production, the cart has a durable surface finish and the mechanism is specially protected against dust damage. See details in Instructions for use.

## SDC 03 Plus

The Sorbent Dispenser Cart has an adjustable magnetic anchor and a magnetic spreader plate. Both elements can be easily operated with the toe of the shoe. This makes operation of the cart quicker and easier. The magnetic elements listed on the SDC 03 Plus version can be purchased separately to upgrade the SDC 03 version.

### Attention!

This product is not intended for use with abrasive materials and de-icing salt! The cart must be cleaned after each use. Follow the Instructions for use.

Dimensions when deployed (in)	width 24, depth 15 (with the handle extended), 51
Dimensions when dismantled (in)	width 24, depth 8 (height with inserted handle), 30
Wheel diameter (in)	7
Maximum volume (gal)	17
Pack size (in)	31 × 29 × 11
Weight of empty cart (lb)	29

